

Introduction to Casa

Kazi Rygl



EUROPEAN ARC
ALMA Regional Centre || Italian



The ALMA measurement set

CASA is a set of C++ application libraries running through a python interface. The software has been designed to calibrate, edit, image, and analyze interferometric and single dish data, in particular the ALMA and JVLA data.

The native uvdata format is the measurement set (*.ms).

A measurement set with a large number of tables, containing the observed visibilities, various calibration tables, flags and models.

ms main table

ms sub tables

```
localhost:working kazi$ ls uid__A002_Xa0b40d_X3cb8.ms
ANTENNA/
ASDM_ANTENNA/
ASDM_CALATMOSPHERE/
ASDM_CALWVR/
ASDM_RECEIVER/
ASDM_SOURCE/
ASDM_STATION/
CALDEVICE/
DATA_DESCRIPTION/
FEED/
FIELD/
FLAG_CMD/
HISTORY/
OBSERVATION/
POINTING/
POLARIZATION/
PROCESSOR/
SORTED_TABLE/
SOURCE/
SPECTRAL_WINDOW/
STATE/
SYSCAL/
SYSPower/
Source.xml
WEATHER/
casapy-20160203-115402.log
ipython-20160203-115403.log
table.dat
table.f1
table.f10
table.f11
table.f12
table.f13
table.f14
table.f15
table.f16
```

```
table.f17
table.f17_TSM1
table.f17_TSM2
table.f17_TSM3
table.f17_TSM4
table.f18
table.f19
table.f2
table.f20
table.f20_TSM0
table.f21
table.f21_TSM1
table.f21_TSM2
table.f21_TSM3
table.f21_TSM4
table.f22
table.f22_TSM1
table.f22_TSM2
table.f23
table.f23_TSM1
table.f23_TSM2
table.f24
table.f24_TSM1
table.f24_TSM2
table.f24_TSM3
table.f24_TSM4
table.f3
table.f4
table.f5
table.f6
table.f7
table.f8
table.f9
table.info
table.lock
```

The ALMA measurement set

Organized in a MAIN table with four columns:

Data - Model - Corrected data - Flags

The original visibilities are never overwritten when calibration or flags are applied, but copied with applied correction/edit to corrected data column. The ms structure stays always the same

MAIN	Model, e.g.:	Corrected data	Flags
Original visibility data	<i>FT of image made from MS</i> <i>FT of supplied model image</i> <i>FT of calibrator flux density</i>	<i>Copy of visibilities with calibration tables applied</i> (Used in imaging but not calibration)	(Edits are stored here first; backup tables can be made and used to modify)


Starting Casa

- Start Casa by:

```
$ casapy
```

When starting Casa, a logger window opens up - in which the history and the output of the tasks is written.

When exiting casa the logger content gets written into casapy-*.log and all the commands given will finish in ipython*.log



Most common commands

to obtain the list of tasks

```
$> tasklist
```

to see the input of a task

```
$> inp listobs
```

launch task

```
$> go listobs
```

to run a file

```
$> execfile('name_of_file')
```

to obtain the previously used parameters

```
$> tget concat
```

to obtain the task in default setting

```
$> default('split')
```

to see the summary info of a task and about its adverbs

```
$> help flagdata
```

open help menu with `$> help` to get info on modules (casa tasks), keywords (python keywords, such as if, from and while) and topics (python objects such as floats, classes)

Casa tasks

Inp flagdata shows the arguments of the task

blue - not a default value, needs to be set

black - default value

red - erroneous value (here, missing “)

green - sub parameters

```
CASA <37>: inp
-----> inp()
# flagdata :: All-purpose flagging task based on data-selections and flagging modes/algorithms.
vis                = 'uid__A002_Xa0b40d_X3cb8.ms.split.cal' # Name of MS file or calibration table to flag
mode               = 'manual'                               # Flagging mode
  field            = 18                                     # Field names or field index numbers: '' ==> all, field='0~2,3C286'
  spw               = 1                                     # Spectral-window/frequency/channel: '' ==> all, spw='0:17~19'
  antenna           = ''                                   # Antenna/baselines: '' ==> all, antenna='3,VA04'
  timerange         = ''                                   # Time range: '' ==> all, timerange='09:14:0~09:54:0'
  correlation        = ''                                   # Correlation: '' ==> all, correlation='XX,YY'
  scan              = 8                                     # Scan numbers: '' ==> all
  intent            = ''                                   # Observation intent: '' ==> all, intent='CAL*POINT*'
  array             = ''                                   # (Sub)array numbers: '' ==> all
  uvrange           = ''                                   # UV range: '' ==> all; uvrange='0~100klambda', default units=meters
  observation        = ''                                   # Observation ID: '' ==> all
  feed              = ''                                   # Multi-feed numbers: Not yet implemented
  autocorr          = False                                # Flag only the auto-correlations

action             = 'apply'                               # Action to perform in MS and/or in inpfiler (none/apply/calculate)
  display           = ''                                   # Display data and/or end-of-MS reports at runtime (data/report/both).
  flagbackup        = True                                 # Back up the state of flags before the run

savepars           = False                                 # Save the current parameters to the FLAG_CMD table or to a file
async              = False                                 # If true the taskname must be started using flagdata(...)
```

CASA <38>:

CASA <39>:

CASA <40>:

Data selection

field='Tita*' - use * as a wildcard

field='2' - use field_id as name

spw="" - selects all spw

spw='1~3' - selects spw 1,2,3 (~ gives a range)

spw='2:100~200,3' - selects chan 100 to 200 from spw2, and spw3


antenna='DV01' - selects all baselines with DV01

antenna = '!DV01' - selects all baselines except those with DV01


timerange = '06:24:00~06:30:00' - selects timerange

timerange = '<06:30:00' - selects times before a given time

Visualization of visibilities and calibration tables: plotms



visualization of images and image analysis: viewer



The right Casa version

- On the Casa website there are many versions (latest version 4.5.1)
- ALMA Archive data comes in raw format with a calibration script, which was created during quality assurance analysis of the dataset (ALMA data are delivered calibrated and with the proposed rms and resolution verified)
- To reduce your Archive data, you need to run the calibration script (scriptForPI.py) in the same version of Casa.

```
$> execfile('scriptForPI.py')
```

- If the data calibration was done by the pipeline (pipeline reduced data have a PPR*.xml file in the script directory), then you need to download the pipeline version of CASA


- start casa pipeline version:

```
$ casapy --pipeline
```

Casa online tutorials & documentation

Casaguides for ALMA: explain not only Casa commands but also ALMA data reduction (<https://casaguides.nrao.edu/index.php/ALMAguides>)

Cookbook and reference manual: recipes and detailed information on Casa tasks (<http://casa.nrao.edu/docs/UserMan/UserMan.html>)



The screenshot shows the ALMAguides website interface. At the top, there's a navigation bar with tabs: 'page' (selected), 'discussion', 'view source', and 'history'. A 'log in' link is in the top right corner. The main heading is 'ALMAguides'. Below it is a sub-heading 'How to use these CASA Tutorials'. The main content area is titled 'Imaging Tutorials for CASA beginners' and includes an introductory paragraph: 'If you are new to CASA, start with the following tutorials. ALMA data are delivered with standard calibrations applied and they are ready for imaging. These guides cover the basic steps required for imaging and self-calibration.' This is followed by a bulleted list of four tutorials: 'A first look at imaging in CASA', 'A first look at self-calibration in CASA', 'A first look at spectral line imaging in CASA', and 'A first look at image analysis in CASA'. Below this is a section titled 'Guides for reducing ALMA Science Verification data' with a paragraph explaining that the links lead to overview pages for each science verification observation. It then lists several specific guides: 'TWHydraBand7', 'NGC3256Band3', 'AntennaeBand7', 'IRAS16293Band9', 'File:BR1202 SV Band7 Calibration notes.pdf', and 'ALMA2014_LBC_SVDATA'. On the left side of the page, there's a sidebar with the NRAO CASA logo, a 'Main Page' link, a search box with 'Go' and 'Search' buttons, and a 'tools' section with links for 'What links here', 'Related changes', 'Special pages', 'Printable version', 'Permanent link', and 'Page information'.

